

# FLO4

controlX

## Semi Automatic Water Level Controller

User Manual


Type	Manual Start - Auto Stop
Operating Voltage	5v DC - Micro Usb
Output Type	Switch Type
Max Motor Load	40 Amp / Upto 5 HP
Device Wattage	Below 1 Watt
Compatibility	Single Phase Motors
Num Of Sensors	2

Manufactured & Marketed By Ecmae Engineering Co.  
Plot No 94, Wazirpur Road, Nehar Par, Faridabad, Haryana 121002

8448865789 | [hello@controlx.in](mailto:hello@controlx.in) | [www.controlx.in](http://www.controlx.in)

**18 MONTHS  
GUARANTEE**

[www.controlx.in  
/terms-and-conditions](http://www.controlx.in/terms-and-conditions)



## Important Notes For Installation

- Install in a clean area, protect from water & dust.
- Stop level should be lower from the ball valve / inlet.
- Water should not fall directly onto the sensors.

# HOW TO USE ?



## Usage

Press Start to instantly Start the motor  
Blue LED will light up.

The motor will Auto Stop when the tank gets full.  
Green LED will light up.

**Use the STOP button, incase you wish to stop the motor early.**